



## **Nissan GU Patrol RD28 2000-2015 Wagon**

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting flex pipe and gear box bracket from the vehicle.
3. If you purchased our dump pipe back system continue with step 8.
4. Remove turbo dump pipe heat shield.
5. Remove turbo dump pipe. We advise to spray the 4 bolts with WD40 before removing.
6. Insert the supplied EGT plug into the turbo dump pipe.
7. Fit the turbo dump pipe using the supplied M10x1.5 nuts and M10x1.5 studs and then tighten.
8. Fit the front pipe section to the dump pipe and tighten finger tight with the supplied 3/8 UNC nuts.
9. Fit the flex join pipe to the front pipe section with the longer side of the flex pipe going towards the front of the vehicle and then tighten finger tight with the supplied 3/8 UNC nuts.
10. Fit the pipe only/resonator or muffler section to the flex pipe and tighten finger tight with the supplied 3/8 UNC nuts.
11. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.
12. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
13. Enjoy your IGNITE exhaust!