



Toyota Hilux 3.0L D4D 2005-2014

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting pipe from the vehicle.
3. Remove catalytic converter from the vehicle.
4. Remove turbo dump. We advise to spray the 3 nuts with WD40 before removing. Hint: It is easier to locate the turbo nuts from underneath the car using a 12mm spanner or single hex socket for the top turbo nut.
5. Insert the supplied EGT plug into the turbo dump pipe.
6. Fit the turbo dump pipe to the turbo outlet flange using the three supplied M8x1.25 nuts. Tighten all 3 nuts.
7. Fit the cat/cat delete flex pipe to the turbo dump pipe and tighten finger tight with the supplied 3/8 UNC nuts.
8. Fit the connecting pipe to the cat/cat delete flex pipe and tighten finger tight with the supplied 3/8 UNC nuts. (Fit diff pipe section in the same format if that's what you purchased and then continue with step 11)
9. Fit the pipe only/resonator or muffler section to the connecting pipe and tighten finger tight with the supplied 3/8 UNC nuts.
10. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.
11. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
12. Enjoy your IGNITE exhaust!