



Toyota Landcruiser 200 series 4.5L twin turbo DPF model 2016 onwards

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting and DPF pipe from the vehicle.
3. Fit the DPF pipes to the DPF flanges using the factory spring loaded bolts and factory nuts and bolts.
4. Fit the pipe only/resonator or muffler section to the DPF pipe and tighten finger tight with the supplied 3/8 UNC nuts.
5. Fit the over diff pipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.
6. Fit the tail pipe section to the over diff pipe and tighten finger tight with the supplied 3/8 UNC nuts.
7. Fit the rear chrome tip with the supplied 3-inch band clamp.
8. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
9. Enjoy your IGNITE exhaust!