



Fitting Instructions – IGNITE 3" Exhaust System

Vehicle Application: Mazda BT-50 3.0L 4JJ3

Before You Begin:

Ensure the vehicle is securely parked on a flat surface and safely supported. Always allow the exhaust system to cool down before commencing removal or installation.

Installation Steps

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting and DPF pipe from the vehicle.
3. Using the factory DPF flange nuts fit the DPF flex pipe and tighten finger tight.
4. Fit the connecting pipe to the DPF pipe and tighten finger tight with the supplied 3/8 UNC nuts.
5. Fit the pipe only/resonator or muffler section to the connecting pipe and tighten finger tight with the supplied 3/8 UNC nuts.
6. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.
7. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
8. Enjoy your IGNITE exhaust!

Playtime Auto Parts (Aust) Pty Ltd.

ACN: 169 674 373

1 Bubeck Street, Sunbury VIC 3429 – Ph: 1300 12 13 12